

CANOLFAN TYWI



TYWI CENTRE



Age and History

Architectural periods, style and design

Architectural periods

- **Mediaeval - 1066 – 1500**
- **Tudor 1500 – 1558 Elizabethan 1558 – 1603**
- **Jacobean 1603 – 1625 English Baroque 1666 – 1714**
- **Early Georgian 1714 – 1765**
- **Late Georgian 1765 – 1811**
- **Victorian 1837 – 1901**
- **Edwardian 1901 – 1914**

Mediaeval - 1066 – 1500



Mediaeval Llwyn Celin



Tudor 1500 – 1558



Tudor
Little Moreton Hall

Tudor 1500 – 1558

Hendre'r-ywydd Uchaf



Hampton Court Palace

Elizabethan 1558 – 1603



Hardwick Hall

Jacobean *1603 – 1625 and* English Baroque *1666 – 1714*



The Queen's House



Crewe Hall

Jacobean *1603 – 1625 and* English Baroque *1666 – 1714*



Plas Tirion



Abernodwydd

Early Georgian 1714 – 1765



Cribyn cottage



Llanelly House

Early Georgian 1714 – 1765



Late Georgian *1765 – 1811*



Royal Crescent, Bath

Late Georgian 1765 – 1811



Georgian townhouse terrace and town square

Regency 1811 – 1837



Victorian 1837 – 1901



Victorian 1837 – 1901



Victorian 1837 – 1901



Victorian 1837 – 1901



Victorian 1837 – 1901



Edwardian 1901 – 1914



Between the wars



What is important?

- **Nearly all the buildings are “solid wall construction**
- **The majority of the materials are “breathable”**
- **Most materials were locally sourced**
- **All of the buildings have a high level of embodied energy – re-use and adaptation reduces emissions and requires less new raw materials**